

Accessories

Commuter Headlamp and Bracket Kit with TurboCharger

Kit Number: 1749700001

Contents

- Segway™ Mounting Bracket
- Light & Motion Commuter Headlamp with TurboCharger

Tools Required

None



WARNING

Riding a Segway Human Transporter (HT) in the dark, even with a lighting system, is an inherently dangerous activity. In order to ride your Segway HT safely, you must be able to clearly see the area in front of you so that you can avoid obstacles, slippery surfaces, loose materials, signs, tree branches and other low overhead dangers, and other potentially hazardous conditions that could cause collisions or falls. Hazardous conditions that are visible in daylight will not be as visible after sunset, even with a headlight. If you cannot clearly see the area in front of you, you should not ride your Segway HT over it. If you ride after sunset, use a familiar, well-lighted route. Always wear a helmet.

Also, you must be clearly visible to motor vehicle drivers and others. When you ride after sunset, wear reflective clothing and display lights visible to the front, sides, and rear. Segway recommends that riders use both a headlight and a red indicator light that is visible from the sides and rear, either mounted on the Segway HT or on the rider.

Some states and municipalities specify the lights that Segway HT riders must use when riding after sunset. Be sure to check local laws.

Because of the increased risk of injury, only experienced, adult riders should ride after sunset.

Instructions

Step 1 - Select Bracket Location

Position the Bracket as high as possible on the control shaft so that the headlamp will not be obstructed by any other accessories. For the headlamp included in this kit, the Bracket must be installed with the mounting post extending to the right.

Step 2 - Attach Bracket

Wrap the Bracket strap around the control shaft and thread through the plastic ring. Pull the strap tight and secure using the hook and loop closure.

Step 3 - Headlamp Installation, Use, and Battery Charging

Mount the headlight to the Bracket mounting post according to the instructions provided by the headlight manufacturer (included with this kit). Use the headlight and charge the headlight battery in accordance with those instructions.

Step 4 - Install Battery

Thread the hook and loop closure strap though the rubber with the hook and loop closure facing away from the battery.

Step 5

Position the battery on the control shaft so that the indentations on the battery case contact the inside of the control shaft (towards the rider).

Step 6

Wrap the strap around the battery, and the control shaft and thread through the plastic ring. Pull the strap tight and secure using the hook and loop closure.

Step 7

Plug the headlamp into the battery pack using the cord provided.

LIMITED WARRANTY The Bracket is an accessory covered by the Segway Muman Transporter Limited Warranty (copy delivered with this kit). The Commuter Headlamp with Turbo Charger is covered by the Warranty provided by the manufacturer. Segway LLC does not warrant the Commuter Headlamp with Turbo Charger and expressly disclaims all implied warranties, including any implied warranty of merchantability or fitness for any particular purpose.



Questions?

If you are missing a part, or if you have any questions, please contact Segway Customer Service at 866.4SEGWAY (886.473.4929) or www.segway.com/support/contact_us.html.

Thank you.